

This is the NON-Contact Moisture Meter, it is an electronic dampness indicator with a measuring process working on the principle of high frequency. The instrument is used for non-destructively tracing of dampness in building materials of all kinds as well as for detecting damp distribution in walls, ceilings and floors. It is particularly suitable for pre-testing the readiness of building materials for covering prior to CM measurement.



DT-128M

PINLESS MOISTURE METER

- I Quickly indicates the moisture content of materials
- I CM % measured function
- I Depth of penetration about 20-40mm
- I Measure and HOLD Function
- I MAX/MIN display Function
- I Alarm Function
- I Low battery indication
- I Auto Power Off
- I White Backlit LCD Display



Button on both sides of the rugged housing, easy to use

General Specifications

| Measuring Range | 0.0-100.0 | |
|-------------------|-----------------------|--|
| Penetration Depth | 20-40mm | |
| Resolution | 0.1 | |
| Battery | Three "AAA" Batteries | |

Moisture Table of Comparison

| Construction Material | Display (Unit) | Moisture Status |
|-----------------------|----------------|-----------------|
| Gypsum | <30 | DRY |
| | 30-60 | RISK |
| | >60 | WET |
| Cement | <25 | DRY |
| | 25-50 | RISK |
| | >50 | WET |
| Wood | <50 | DRY |
| | 50-80 | RISK |
| | >80 | WET |

Accessories

Battery, Carrying Case, Instruction Manual, Test Certificate



Contact:

CEM INSTRUMENTS (INDIA) PVT. LTD.

32A, Ganesh Chandra Avenue, 4th Floor, Kolkata-700013 Tel: 033-22151376, 22159759

Email: info@cem-instrumets.in / info@cem-india.com Web: www.cem-instruments.in / www.cem-india.com

CEM INSTRUMENTS HEADQUATER & FACTORY

19th Building, 5th Region, Baiwangxin Industry Park, Songbai Road, Baimang, Xili, Nanshan, Shenzhen, China, 518108

Tel: +86-755-27353188, Fax: +86-755-27653699